



PRODUCT CODE: RE-GFILT-ABEK1

PRODUCT DESCRIPTION: Gas Filter Cartridges ABEK1 for Half Mask Respirator with Double Cartridge

MATERIALS AND FEATURES

REBEL GAS FILTER – ABEK1 gas cartridges are used in conjunction with REBEL REUSABLE HALF MASK DOUBLE CARTRIDGE respirators (RE-HALMADBL), filtering certain organic gases and vapours, certain inorganic gases and vapours, sulphur dioxide and other acidic gases and vapours, as well as ammonia and organic ammonia derivatives.

CERTIFICATION

EN/ISO REQUIREMENT	EN14387: 2004 + A1:2008
SABS	SANS 54387:2007
NRCS	NRCS: NRCS/8072/0411
CE REQUIREMENT	CE 2834 Regulation (EU) 2016/425

SPECIAL INSTRUCTIONS/WARNINGS

Please read user instructions in full before wearing this mask – refer to www.rebelsafetygear.com

Only to be used in conjunction with REBEL Half Mask Respirator with Double Cartridge – supplied separately.

If either product is used with another brand, we cannot be held responsible for the efficacy of the product.

Do not use where:

- Oxygen concentration is less than 19.5%.
- Contaminants or their concentrations are unknown or are known to be immediately dangerous to life or health. Particulate or gas concentrations exceed levels fixed by the applicable health and safety regulations.
- Not to be used for firefighting.
- Do not use in explosive atmospheres.

These cartridges do not supply oxygen. DO NOT use in oxygen deficient atmospheres (e.g. tanks or other poorly ventilated areas).

A Gas Filter must be replaced once chemical breakthrough can be determined by smell, taste or any other means. Please read the user instructions to determine when they must be replaced.

The REBEL GAS FILTER CARTRIDGE is for use with TWIN filter masks only.

CARE/STORAGE	
STORAGE INSTRUCTIONS	<ul style="list-style-type: none">Gas filter shall be stored in a dry, clean, low humidity environment.Store between temperatures of -10 and +30 degrees Celsius, and where relative humidity is <70%.
CARE INSTRUCTIONS	<ul style="list-style-type: none">The exterior of the filter can be cleaned with the use of a dry cloth.Solvents must not be used for cleaning and care should be taken to ensure no water enters the filter.
SHELF LIFE	<ul style="list-style-type: none">5 years from date of manufacture, provided it is still in its original, sealed packaging.The expiry date of each item is indicated on the packaging and on the cartridge.
DISPOSAL	<ul style="list-style-type: none">All industrial waste should be disposed of correctly according to local regulations and good disposal practice.Respiratory protective devices should be disposed of considering the hazardous substance they were used for.Please consider recycling.
OTHER INFORMATION	
SIZING	One size
PACKAGING	1 pair per packet, 30 packets per carton